

# Understanding your weights

**VEHICLE TARE WEIGHT = Weight of Vehicle + Oil & Fluids + 10L Fuel**

**VEHICLE KERB WEIGHT = Weight of Vehicle + Oil & Fluids + Full Tank of Fuel**

**VEHICLE PAYLOAD = GVM – Vehicle Kerb Weight**

**GCM = Maximum Allowable Weight of Vehicle + Trailer (Caravan)**

**GVM = Maximum Allowable Weight of Vehicle**

**TBW = Tow Ball Weight**

**ATM = Maximum Allowable Weight of Caravan**

**GTM = Gross Trailer Mass (ATM – TBW)**

**CARAVAN TARE WEIGHT = Weight of Caravan + Factory-fitted Accessories**

**CARAVAN PAYLOAD = ATM – Caravan Tare Weight**

